How to check PC or Notebook Network adators

GO to search key "Device manager"

	Ľ	ŝ		Filters 🗸		
Best match						
		e Manage ol panel	r			
Settings						
🖚 Update device drivers						
				0		
				2		
0		1		2		
ρ d	levice r	nanager				

Select Network adaptors follows step accordingly below

🛃 Device Manager		— 0 ×
File Action View Help		
Find the set of the	Realtek PCIe GBE Family Controller Properties X Everts Benorres General Advanced About Driver Determine About Driver Details The property that you want to change on the left and then select to value on the right. Value: Property: Value Nords 3 VLAN Prover Strange Receive Suffers Receive Suffers Receive Suffers To Moos Hall Duplex To Moos Hall Duplex To Moos Hall Duplex TO PORS-Asam Official (Prk) To Moos Hall Duplex TO PORS-Asam Official (Prk) To Moos Hall Duplex TO PORS-Asam Official (Prk) To Moos Hall Duplex WOL & Shuddown Link Speed Value	step 6
> 4 Sound, vide and game controllers > Say Storage controllers > 1 System devices > ♥ Universal Serial Bus controllers	OK Cancel]
🖶 A 🗆 🤌 🚳 🌖 🕰 🔚	🗙 🛃 🥥 dag - Salahar	- ∧ 🗈 🦟 d0) ENG 12:19 PM 🖏